BlackBerry Torch

Explore

BlackBerry Torch 9800 Smartphone

Home

Lock/unlock the screen
Press the Lock key

Change your ring tone or set other alerts
Tap the sounds icon

Open an application
Tap the icon. Touch and hold the icon to open a pop-up menu of common actions.

Quick access area
Tap the top of the screen to change your connection settings, set the alarm, or see your service status. Tap under the time to see a list of new or unopened items.

Search for an item
Tap the search icon

View more applications
Tap or slide your finger up on the Navigation bar. Slide left or right to see other views.

Return to the Home screen
Press the End key. Press and hold to turn on/off your BlackBerry® device.

Open the menu or application switcher
Press to open the menu. Press and hold to switch applications.

Navigate the screen
Slide your finger on the trackpad or screen. To select an item, click (press) the trackpad or tap the screen.

Phone

View your call history

Dial a number

Check your voice mail
Touch and hold the 1 key

Make a call or open the Phone application
Press the Send key. To answer a call, press the Send key or open the slider.

View your contacts

Delete key

Set up a speed dial number
Touch and hold a number key

End a call

Open the menu

Contacts

Add a contact
Tap New Contact. To add a contact from a recent call in your call history, touch and hold the phone number and tap Add to Contacts.

Open the touch screen keyboard

Search contacts
Tap the search bar to open the touch screen keyboard

Pop-up menu
Touch and hold a contact to open a pop-up menu of common actions. To open the full menu, tap the Full Menu icon or press the Menu key.

Camera

Zoom in or out
Slide your finger up or down on the screen or trackpad

Add your location info to the picture

View pictures

Take a picture
Tap the camera icon to focus. Tap again to take a picture.

Zoom indicator

Take a picture
Press the Convenience key to open the camera. Press it again to take a picture.

Change the flash setting

Change settings for optimal pictures

©2010 Research In Motion Limited. All rights reserved. BlackBerry®, RIM®, Research In Motion®, SureType®, SurePress™ and related trademarks, names and logos are the property of Research In Motion Limited and are registered and/or used in the U.S. and countries around the world. All other trademarks are the property of their respective owners. This documentation is provided "as is" and without condition, endorsement, guarantee, representation or warranty, or liability of any kind by Research In Motion Limited and its affiliated companies, all of which are expressly disclaimed to the maximum extent permitted by applicable law in your jurisdiction.

MAT-34087-001 | PRINTSPEC-089 | SWD-1084988-0810092457-001 | RCY71UW/RDG71UW

Pictures

Zoom/pan
To zoom, slide your finger and thumb together or apart, or click the trackpad. To pan a zoomed picture, slide your finger on the screen or trackpad.

Rotate picture

Send picture

Play slideshow

Open the pop-up menu
Touch and hold the screen, or press and hold the trackpad.

Scroll through pictures
When zoomed out, slide your finger left or right quickly on the screen or trackpad

Zoom/pan indicator

Previous/next picture

Return to the previous screen

Browser

Type an address
Tap the address bar to open the touch screen keyboard

Open a pop-up menu
Touch and hold the screen to open a pop-up menu of common actions. Send a webpage address, add the page to your bookmarks, or send an image.

Open tab view

Open your bookmarks and history

Zoom/pan
To zoom, slide your finger and thumb together or apart, or click the trackpad. To pan a zoomed page, slide your finger on the screen or trackpad.

Tab view
To see the tabs you have open, slide your finger on the screen or trackpad. To open a tab, tap the thumbnail or click the trackpad.

Close the selected tab

Open a web page in a new tab

Messages

Pop-up menu
Touch and hold a message to open a pop-up menu of common actions. Reply to or forward a message, flag it for follow up, file it, or delete it.

Search messages

Date
Tap to see more ways to navigate and manage your messages

Open a message
Tap a message

Open a message
Click the trackpad to open the highlighted message, or tap a message on the screen.

Cut, copy, and paste

Select text
Touch the beginning and end of the text. You can select text to cut and copy from many applications and paste it into text fields.

Cut

Copy

Open the pop-up menu
Touch and hold the screen, or press and hold the trackpad

Move the cursor
Touch the cursor frame and slide your finger

Cancel selection

Type text

Pop-up menu
Touch and hold the screen or press and hold the trackpad to open the pop-up menu

Type numbers
Tap the 123 key to switch to numbers. Touch and hold to turn on number lock.

Slide-out keyboard
When the slider is fully open, the touch screen keyboard disappears and the screen uses portrait view.

Touch screen keyboard
To type in either portrait or landscape view, rotate your device. To hide the keyboard, touch the top of the keyboard and slide your finger quickly down the screen.

Capitalize a letter
Touch and hold a letter to capitalize it. Touch and hold the Shift key to turn on capital letter lock.

Insert a symbol